<u>hivolt.de</u>

SHV - STRAIGHT CABLE PLUG & SEALED BULKHEAD RECEPTACLE 5kVpc / 3.5kVrms

FEATURES

- Rated Voltage 5kVpc / 3.5kVrms
- Rated Current 500mA
- Completed cable assemblies available
- RoHS compliant

APPLICATIONS

- Safe high voltage laboratory wiring
- High voltage power supplies / amplifiers
- Nuclear instrumentation
- Test and measurement equipment

DESCRIPTION

SHV (**S**afe **H**igh **V**oltage – Nuclear Instrumentation Module Standard) reverse polarity, coaxial high voltage connectors.

The straight cable plug 57K101-106N3 and the rear mount bulkhead crimp receptacle 57S507-106N4 are compatible with standard RG58-C/U or our 20kV rated LSZH **HRG58-20-2** coaxial cable for crimp assembly. For high temperature applications it can also be assembled with silicone or FEP insulated coaxial cable **HSL-10S-0.5-A-2** or **HRG303-40-U-A-2**, respectively.

The outer ground connection is maintained during unintended mating/unmating. The center contacts are recessed to prevent shock hazard when the connectors are mated. For personal safety the connectors must not be mated or unmated when energized! The connectors are RoHS compliant.

Remark: SHV and BNC connectors are not intermateable.

SPECIFICATIONS

Impedance: Frequency: Insulation resistance: Center contact resistance: Outer contact resistance: Operating voltage: Test voltage:

Operating current:

Mating cycles: Coupling nut retention: 57K101-106N3 Center contact captivation: 57S501-200N3 57S507-106N4

Operating temperature: Weight **57K101-106N3 57S501-200N3 57S507-106N4** 50Ω DC to 300MHz > 1000GΩ < 2mΩ < 1.5mΩ max. 5000Vpc / 3500VRMS min. 10000Vpc / 5000VRMS (at sea level) 500mA (average) / 10A (peak)


min. 500 (cable plug) > 450N (bulkhead receptacle) > 18N (axial) / > 3Ncm (radial) > 27N (axial) / > 3Ncm (radial)

-55 to +155°C 20.4g 11.0g 30.0g









57_SHV 07/2025 Page 1 of 4

hivolt.de


Material and plating

Connector part	Straight Cable Plug 57K101-106N3		
	Material	Plating	
Center contact	Beryllium copper	Gold, min. 1.27µm, over nickel	
Outer contact	Beryllium copper	Flash white bronze over silver	
Body	Brass	Flash white bronze over silver	
Dielectric	PTFE	-	
Gasket	Silicone	-	


Connector part	Bulkhead Receptacle 57S501-200N3		Bulkhead Receptacle 57S507-106N4	
	Material	Plating	Material	Plating
Center contact	Brass	Gold, min. 1.27µm, over nickel	Brass	Gold, min. 0.8µm, over nickel
Outer contact	Brass	White bronze	Brass	Flash white bronze over silver
Body	Brass	Flash white bronze over silver		
Dielectric	PTFE		PTFE	
Gasket	NBR			
Crimping ferrule			Copper	Flash white bronze over silver

DIMENSIONS

- STRAIGHT CABLE PLUG 57K101-106N3



- FRONT MOUNT BULKHEAD RECEPTACLE 57S501-200N3




Dimensions are in mm. Drawings not to scale.

 $\ensuremath{\mathbb{C}}$ 2025 hivolt.de - Subject to change without notice, errors excepted

57_SHV 07/2025 Page 2 of 4

<u>hivolt.de</u>


- REAR MOUNT BULKHEAD CRIMP RECEPTACLE 57S507-106N4




Dimensions are in mm. Drawings not to scale.

PANEL CUT-OUT

- FRONT MOUNT RECEPTACLE 57S501-200N3



- REAR MOUNT RECEPTACLE 57S507-106N4



ORDERING INFORMATION

SHV Straight Cable Plug (female)	57K101-106N3			
SHV Bulkhead Receptacle (male)				
Front Mount, Solder: Rear Mount, Crimp:	57S501-200N3 57S507-106N4			

The SHV plug can be assembled by the user (see next chapter for assembly instructions).

Bespoke ready-to-use high voltage cable assemblies based on several high voltage cable types are available. The cable assemblies are fully tested. Please contact hivolt.de for details.

Examples:

Cable: HRG58-20-2; Length: 2m; SHV plug assembled on both sides Cable: HSL-10S-0.5-A-2; Length: 80m; SHV plug assembled on one side HCA-005-S01-002-S01-A HCA-005-S01-080-B

ACCESSORIES	
Bend Relief for Cable Plug	71Z526-006SW
CRIMP DIMENSIONS	
SHV Straight Cable Plug	57K101-106N3 ferrule: HEX 5.35mm, center pin: HEX 1.75mm
SHV Bulkhead Crimp Receptacle	57S507-106N4

57S507-106N4 ferrule: HEX 5.50mm, center pin: HEX 1.75mm

© 2025 hivolt.de - Subject to change without notice, errors excepted

57_SHV 07/2025 Page 3 of 4

<u>hivolt.de</u>

ASSEMBLY INSTRUCTIONS – CABLE PLUG

1.

Components of the connector:

- A: ferrule
- B: center pin
- C: connector body

2.

- If a bend relief should be used, slide it onto the cable (recommended).
- Slide ferrule A onto the cable.
- Remove cable jacket according to the diagram
- ⚠ Do not damage the shield wires!
 - Shorten the braid and remove the dielectric insulation according to the diagram (dimensions in mm).
- ⚠ Do not damage the dielectric insulation!
- Carefully remove loose shield wires completely. Loose shield wires can cause electrical breakdown.

3.

- Push center pin B over the inner conductor of the cable up to the dielectric and crimp or solder.
- Splay out the braid.

4.

- Insert the prepared cable into the connector body C until the center pin engages perceptibly. Ensure that the braid covers the knurled connector end.
- Slide ferrule A over the braid up to the connector body and crimp as close to the connector body as possible.
- If present, slide the bend relief over the ferrule and push it firmly against the connector body.

⚠ Important notes:

- 1. Carefully read assembly instructions before starting the assembly process.
- 2. Cable assembly must only be done by trained and qualified personnel.
- 3. Insulation and conduction properties of the completed cable assembly must be tested prior to operation.

Disclaimer


The information given in this data sheet is technical data, not assured product characteristics. It has been carefully checked and is believed to be accurate; however, no responsibility is assumed for inaccuracies. The user has to ensure by adequate tests that the product is suitable for his application regarding safety and technical aspects. hivolt.de GmbH & Co. KG does not assume any liability arising out of the application or use of any product described.


Safety Advice


Design, installation and inspection of machinery and devices carrying high voltage require accordingly trained and qualified personnel. Appropriate safety rules and directives must be complied with.


Improper handling of high voltage can mean severe injuries or death and may cause serious collateral damage!

© 2025 hivolt.de - Subject to change without notice, errors excepted









57_SHV 07/2025 Page 4 of 4